VERTICAL FRAMING
(NOT BY IMP SUPPLIER)

"OC-02 " OUTSIDE CORNER
W/ #10 x $\frac{3}{4}$" PPH 12" O/C

"WC-01" PANEL CLIP W/
(_) $\frac{1}{4}$ - 14 x _ TEK 3 FASTENERS
W/O WASHER AT PANEL JOINT

"IC-02 " INSIDE CORNER W/ POP RIVETS
12" O/C (SET TRIM IN $\frac{3}{8}$" DIAMETER
BEAD OF BUTYL SEALANT)

$\frac{1}{2}$" DIAMETER BEAD
OF BUTYL SEALANT

"WC-01" PANEL CLIP W/
(_) $\frac{1}{4}$ - 14 x _ TEK 3 FASTENERS
W/O WASHER AT PANEL JOINT

CORNER TRANSITION - FLAT INSIDE

(PLAN VIEW)

DETAIL:
CORNER TRANSITION - FLAT INSIDE

APPLICATION:
HORIZONTAL WALL, COMMERCIAL & INDUSTRIAL

AWIP DETAIL NUMBER:
AHW-ACI-CT-002

DATE:
02/07/23

DRAWN BY:
MMF