



NOTE: ONEDEK® MEMBRANE TO BE INSTALLED PERPENDICULAR TO ROOF SLOPE DIRECTION WITH OVERLAP TOWARDS DRAINAGE POINT.

NOTE: RD1 ROOF DECK PANEL INSTALLATION DIRECTION MAY VARY DEPENDING ON PROJECT.

TRIM EDGE OF OVERLYING SHEET FOR EASY INSTALL OF T-JOINT (RECOMMENDED, BUT NOT REQUIRED)

ONEDEK® ENDLAP AND T-JOINT COVER PATCH DETAILS
(PERSPECTIVE VIEW)

DATE:	10/11/22	SHEET:	1
DRAWN BY:	MMF	OF	1
DETAIL: MEMBRANE ENDLAP AND T-JOINT COVER PATCH DETAILS			
APPLICATION: ONEDEK® FULLY ADHERED, COMMERCIAL & INDUSTRIAL, COLD-STORAGE			
AWIP DETAIL NUMBER: ODR-CICS-MA-001			

929 ALDRIDGE ROAD
VACAVILLE, CA 95688
TEL: (707) 359-2280
FAX: (707) 359-2286
WWW.AWIPANELS.COM

